

ASSEMBLY INSTRUCTION

Item: 5183-75310 Splat Back Side Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'ty
Α		BOLT	Ø5/16"×3-1/2"	4pcs
В		SCREW	8#×1-1/4"	4pcs
С		NUT	Ø5/16"×12	4pcs
D	0	FLAT WASHER	Ø5/16"	9pcs
Е	٧	LOCK WASHER	Ø5/16"	9pcs
F	<u></u>	Wrench	12mm	1pc
G		BOLT	Ø5/16"×1-3/4"	1pc



