






Item: 5795-90851-91 5/0 Upholstered Headboard
 5795-90852-91 5/0 Upholstered Footboard
 5795-90853-91 5/0-6/6 Rail


Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:






HARDWARE PACK RAIL

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
B		Threaded Rod	Φ5/16"×3-1/2"	8pcs
C		Nut	Ø5/16"×12	8pcs
D		Lock Washer	Φ5/16"×12×1	8pcs
E		Curved Washer	L32*13*8	8pcs
F		Hex Wrench	12MM	1pc

HARDWARE PACK FOOTBOARD

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Screw	8#×1"	8pcs

PART LIST

NO	DRAWING	DESCRIPTION	Q'TY
R		Upholstered Headboard	1pc
I		Upholstered Headboard	1pc
H		Rail	2pcs
K		Slats	4pcs
M		Short Support Leg	4pcs

STEP1. Attach Rails (H) to the Headboard Panel + legs (R-M) using Threaded rod (B), Curved washer (E), Nut (C) and tighten them by Open wrench (F)

STEP2. Attach Short support legs (M) to Slats (K)

STEP3. Attach the Slats (K) to the Rails (H) using Screw (A) by the Phillips head screwdriver

