

Assembly Instruction For 9013

- 1.Place the glass on the socket, then secured by metal cap and socket ring
- 2. The another 2PCS as same the step 1

