

# ASSEMBLY INSTRUCTIONS

ITEM NO: BO-2802TB

CAREFULLY UNPACK AND PLACE ALL PARTS ON A SMOOTH SURFACE.

1. SCREW SOCKET ASSEMBLY (E) CLOCKWISE INTO POLE (F) TO TIGHTEN.
2. SCREW POLE (F) CLOCKWISE INTO POLE (G) TO TIGHTEN. AND MAKE THE POLE (G) OF RECTANGULAR METAL PIECE IS AS SAME DIRECTION WITH THE SOCKET (E)
3. SCREW POLE (G) CLOCKWISE INTO BASE (H), MAKE SURE THE RECTANGULAR BASE IS AS SAME DIRECTION WITH THE SOCKET. TIGHTEN NUT (J) AND WASHER (K) WITH SPANNER (L). PULL THE REMAINING SLACK OF THE POWER CORD FROM BASE. PEEL THE COVER OF THE NON-WOVEN PAD AND STICK IT TO THE BOTTOM OF THE BASE.
4. SCREW ROD (D) CLOCKWISE INTO SOCKET (E) TO TIGHTEN.
5. SET WASHER (C) AND SHADE (B) INTO ROD (D) BY FINIAL (A) CLOCKWISE TO TIGHTEN.
6. INSTALL BULB (NOT INCLUDED )INTO THE SOCKET.
7. INSERT THE POWER PLUG INTO AN OUTLET AND ENJOY!!

**Use MAX 2\*60 Wattage type A bulb (bulb not included)**

## IMPORTANT SAFETY INSTRUCTIONS:

### SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.

THIS PORTABLE LAMP HAS A POLARIZED PLUG (ONE BLADE IS WIDER THAN THE OTHER) AS A FEATURE TO REDUCE THE RISK OF ELECTRIC SHOCK. THIS PLUG WILL FIT IN A POLARIZED OUTLET ONLY ONE WAY. IF IT DOES NOT FIT FULLY IN THE OUTLET, REVERSE THE PLUG. IF IT STILL DOES NOT FIT, CONTACT QUALIFIED ELECTRICIAN. NEVER USE WITH AN EXTENSION CORD UNLESS THE PLUG CAN BE FULLY INSERTED. DO NOT ALTER THE PLUG.

