ASSEMBLY INSTRUCTION FOR ITEM: 720125

Note: Please read carefully and save these instructions, as you may need them at a later date.

IMPORTANT SAFETY INSTRUCTIONS: This product has a polarized plug (one blade is wider than the other) as a feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit, contact a qualified electrician. Never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

GENERAL: All electrical connections must be in accordance with local and National Electrical Code (N.E.C.) standards. If you are unfamiliar with proper electrical wiring connections obtain the services of a qualified electrician.

Remove the lamp from the box and make sure that no parts are missing by referencing the illustrations on the installation instructions. \bigcirc

- 1. Fasten the **POLY TUBE** (2) onto the **LAMP BASE**(1). Be careful not to twist he power cord, tighten securely.
- 2.Place POLY TUBE (3) onto POLY TUBE (2).
- 3.Place POLY TUBE (4) onto POLY TUBE (3).
- 4. Place Socket Assembly(5) onto POLY TUBE (4).
- 5.Place HARP(7) onto saddle(6).
- 6.Put SHADE (8) onto HARP (7) and tighten with FINIAL (9).
- 7. Screw a light bulb into the lamp socket and make sure it does not exceed the maximum wattage specified on the lamp wattage rating label, MAXIMUM 150 WATT This 3-way socket is only suited for 3-way bulb, Please do not install normal single-filament bulb into this socket. Otherwise, it may cause short circuit or bulb exploded.



- 8. SHADE
- 9.FINIAL