



INSTALLATION INSTRUCTIONS



P25210



P25010

INSTALLATION INSTRUCTIONS

THANK YOU FOR CHOOSING KALLISTA

We appreciate your commitment to Kallista quality products. Please take a moment to review this manual before you install your Kallista product. If you encounter any installation or performance problems, please do not hesitate to contact us at the phone number listed at the bottom of the page.

BEFORE YOU BEGIN

- Observe all local plumbing and building codes.
- The appearance of the sidespray may differ from the illustrations. The installation instructions still apply.
- Install this product according to the installation guide.

Note: Plumbing codes require an atmospheric vacuum breaker be installed in-line with sidesprays. Ensure that the faucet contains an atmospheric vacuum breaker, or consult with local plumbing officials.

- Kallista reserves the right to make revisions in the design of faucets without notice, as specified in the Price Book.

INSTALLATION

- Ensure that the gasket is installed in the underside of the spray holder.
- Insert the spray holder into the mounting hole.
- From underneath the mounting surface, install the spacer (if needed) and nut. Securely hand tighten the nut.
- Insert the sidespray with sidespray hose through the spray holder.
- Verify the sidespray hose outlet and inlet are clean and verify an O-ring is in place in the sidespray hose inlet.
- Remove the plug from the sidespray outlet (from the faucet). Connect the sidespray outlet hose to the sidespray inlet hose.
- Extend and retract the spray hose to check for smooth operation.
- Reposition the supply hoses if necessary.

