

ASSEMBLY INSTRUCTION

Item: 6033-75400-85 Upholstered Arm Chair

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO DRAWING	DESCRIPTION	SIZE	Q'TY	
A	Hexagonal Bolt	Ø5/16"*3-1/2"	4pcs	
B	Hexagonal Bolt	Ø5/16"*2"	4pcs	
C	Hexagonal Bolt	Ø5/16"*2-1/4"	2pcs	
D 0	Allen Head Bolt	Ø1/4"*1-1/4"	2pcs	
E	Lock Washer	Ø5/16"*12*3	10pcs	
F ©	Flat Washer	Ø5/16"*19*2	10pcs	
G ©	Lock Washer	Ø1/4"*12*3	2pcs	
Н	Flat Washer	Ø1/4"*13*2	2pcs	
I Ø	Dowel	Ø15*Ø13*10	2pcs	
J &	Hex Wrench	12MM	1	↓
K	Allen Key	4MM	1pc	
Step 1		F		Step 2 F E B
D K	G H Step 3	FE	Sto	ep 4 Complete