# **ASSEMBLY INSTRUCTION**

#### QTY NO PART LIST HEADBOARD 1PC 1 CUSHION 2 RIGHT HEADBOARD LEC 1PC WITH 'R' LABEL RIGHT HEADBOARD LEO 3 1PC WITH 'L' LABEL FOOTBOARD 1PC 4 CUSHION FOOTBOARD 2PCS 5 LEGS SIDE RAIL 2PCS 6 SIDE RAIL 2PCS 7 SIDE RAIL 2PCS 8 UPPORT LEG 4PCS SLATS 9 SUPPORT LEGS 4PCS 10 WITH ADJUSTABLE FEET QTY NO HARDWARE LIST JCBB SCREW ())000 8PCS A M8 X 20 JCBC SCREW 8PCS ₿ ()..... M6 X 25 JCBC SCREW 10PCS C Ð M6 X 35 JCBC SCREW 2PCS D M6 X 70 WOOD DOWEL 2PCS E SPRING WASHER | 14PCS F FLAT WASHER | 14PCS G SCREW 8PCS Ħ þw M4 X 32mm L - KEY 1PC I ∍ M5 X 65mm L-KEY 1PC l M4 X 65mm

## STEP 1

Begin assembly by attaching each Headboard leg (2) & (3) to the bottom of the headboard cushion (1) by aligning the hole and securing with 3 Allen Bolts (C), 3 spring washer (F), 3 flat washer (G) per leg using L-key (J).



### STEP 2

Attach each footboard leg (5) to the bottom of footboard cushion (4) by inserting a dowel (E) & securing with 1 Allen Bolt (D) per leg using L-key (J).



# **ASSEMBLY INSTRUCTION**

### STEP 3

Attach side rail support leg (8) to the join of the side rail (6) and side rail (7) by securing with 4 Allen Bolts (B), 4 spring washer (F), 4 flat washer (G) per support using L-key (J).

# STEP 4

Attach side rail to the headboard leg (2) & (3) and footboard (4). Aligning holes and securing with 2 Allen Bolts (A) per each by using L-key (I) .

### (DO NOT FULLY TIGHTEN BOLTS FOR THIS STEP.)



Do not fully tighten screws until assembly is complete and the bed is level

### STEP 5

Attach support legs (10) to slat (9) by securing with 1 Allen Bolt (C) per support. Attach slats (9) to side rail by securing with 1 screws (H) per each side. Tighten all screws using philips head screwdriver (NOT INCLUDED). Tighten all bolts on step 2 & 3 using L-key (J) following step 4 using L-key (I) that has been provided.





STEP 6



ASSEMBLY COMPLETED