

Assembly Instruction For 13503

- 1.Attached the arm on the metal ring then secure by screw and make sure each arm is aligned with the center rod.
- 2. Thread the nipple 1 into the coupler 1 then secure by hex nut 1.
- 3. Attached the cap and top part on the nippler 1 then secure by loop.
- 4. Thread the nipple 2 into the coupler 2 then secure by hex nut 2.
- 5.Attached the tube, tube cover and glass stator on the nipple then secure by hex nut 3.
- 6. Place the glass and glass washer on the nippler 2 then secure by hex nut 4.
- 7. Attached the poly cap on the nipple 2 then secure by finial.

