For Style 9906P31 Assembly Instruction Sheet #IS-9906P31

Required: Flathand screwitiver, Philips screwitiver, plient, wive outlant, wire sitypeen, electrical tape, safety glasses. Source: (8) GD Candelabra Basis 800% Advit Maximum (Not Indude). stated Assembly Times: 20-30 mixutes restor: Harrifly and Impact all parts before beginning Installation. Check package content list and diagrams before to be sure all parts seent. If any parts are missing or damaged, do not attempt to assemble, Install, or operate the fixture. Contact customer service for

⚠ Warnings and Cautions
Tum off electricity at circuit breaker or main fuse box before installation. Consult a licensed electrician if in doubt.
These instructions are provided for your safety. It is very important you read them completely before installing the fixture. We strongly recommend that a licensed, professional electrician perform the installation.
Disconnect fluture from power source before replacing bulbs. Make sure bulbs are given sufficient time to cool



