

ISLAND LEGS INSTALLATION AND WOOD FINISHING TIPS


Things needed:

- Island leg posts
- Pencil
- Wood Glue
- Drill and drill bit
- Measuring tape or ruler
- Screw driver
- Hardwood for frame
- Wood saw
- Chisels

Prepare:


- Measure the Kitchen Island Legs to the proper height of the countertop
- Make a mortise and tenon on each side of the Kitchen Island legs.

There are several ways in attaching post to a Kitchen Island, please note the idea explained here is one of the traditional ways to install it.



Install:

- Good quality wood glue can be used to join the tenon to the mortised Kitchen Island leg.
- Continue with the same process with all Kitchen Island Leg.



Staining Woods

Tools:

- Paint Brush
- Rags
- Pre-Stain Wood Conditioner
- Oil or Acrylic-based Wood Stain
- Oil or Acrylic –based Polyurethane Sealer
- 120 Grit and 220 Grit Sandpaper
- Cheese Cloth towels
- Goggles
- Protective mask

Prepare:

Decide which Type of Stain to use. You could use either an Oil base or Acrylic based Stain. Whichever you decide, you will also be using the same type of Sealer to finish up the staining process. When staining, make sure the room temperature is between 70 and 75 degrees for best results. Also it is very important to test your stain colors on smaller samples of wood so that you know exactly what finish you will achieve.

Steps:

1. **SANDING.** American Pro Décor hardwoods are mostly ready to be stained. However, there will be instances where the wood will need to be sanded down to remove scratches etc. Then brush off any debris so that you could go onto the next step.
2. **PRE-STAINING WOODS.** Not all wood are uniform in color or texture also woods are porous with different densities. Therefore, wood will absorb stain in an uneven manner. To obtain a consistent and even finish, use a Pre-Stain Wood Conditioner found at any home store. The Pre-Stain Wood Conditioner is applied on the raw wood using a cloth or brush. Allow it to penetrate for about 10 to 15 minutes. Remove any excess afterwards. The Stain should be applied with 2 hours.
3. **STAINING.** Apply the stain with a wide brush evenly or rag. It is your choice of which one to use. Make sure your area is well ventilated. Stains will produce fumes. Always apply going with the grain and against the grain as well. The purpose is to apply the stain to cover all visible surfaces. It depends on how light or dark you need the wood to be. If you need a lighter look, wipe off the stain immediately. For a darker tone, leave the stain for 5 to 10 minutes before wiping it. When cleaning off the Stain residue, go in the direction of the grain so that the stain will penetrate into the grain of the wood. If a second coat is required, it is advisable to light sand the wood with the 120 Grit sandpaper and wipe off any debris. BRUSHES are better for staining Ornate Carvings and other hard to reach areas. RAGS are best for flat surfaces. If you are an experienced wood worker, you could achieve an ANTIQUE FINISH by using water down black paint and brush it into the cracks and details of your wood ornaments. After a few minutes of applying the water down black paint, wipe off any surface excess. This will add a beautiful accent to your carved wood ornaments.
4. **SEALING YOUR WOOD.** Remember, stain will only provide color to your wood NOT a finish. Therefore, you need to apply a sealer. Remember to use the same base type of material. That is Oil-based Stain to Oil-based Sealer, acrylic based Stain to acrylic based Sealer. Apply it by using a brush or sprayer. Let it dry. If needed, sand with 220 Grit sandpaper. Wipe clean and apply another coat of the Polyurethane Sealer. Sealers are mostly known as varnish, shellac or wood polish.

American Pro Décor assumes no liability for Improper Installation.