Assembly Instruction For13505



1. Thread the nipple into the coupler then secure by hex nut.

2.Attached the cap,poly pole on the nipple then secure by loop.

3.Place the glass over the socket then secure by socket ring.

