# GOLDBERG BROTHERS, INC.

# **Premium Series Horseshoe Hanger - Installation Instructions**

#### **Included Hardware** Washers (6)

Carriage bolts (6)

Lock washers (6)

Horseshoe hangers (2) Track stops (2)

T-guide (1) T-guide screws (2)

INISHED OPENIN WALL 000



Premium Hardware set installed with no casing, base, or other trim.

#### Premium hardware set installed on track trim board that is equal to or thicker than casing, base, or other trim.



Hex lag bolts (6)

Premium hardware set + 1/2' extension kit installed where casing. base, or other trim is up to 1/2" thick.



Anti-jump blocks (2)

Anti-jump block screws (4)

7/8" or 11/4" Extensions

Spacers (6)

Hex nuts (6)



Premium hardware set + <sup>7</sup>/<sub>8</sub>" or 1<sup>1</sup>/<sub>4</sub>" extension kit installed where casing, base, or other trim is greater than <sup>5</sup>⁄<sub>8</sub>" thick.

## **Door Prep and Hanger Installation**

At 3"and 9" from both sides of the top half of the door, measure down 11/4" and drill 1/8" pilot holes followed by 3/8" holes. 6" from both sides of the top half of the door, measure down 41/2" and drill 1/8" pilot holes followed by 3/8" holes.







In the closed position, the door should overlap the wall a minimum of 3/8" at the top and a minimum of  $\frac{1}{2}$ " on both sides.

The edge of the door should align with the end of the track.

Note: After the door is hung from the track, the antijump blocks can be installed directly behind the horseshoe hangers.

Bumper For each hanger, place one felt pad strip on the track stop or the edge of the hanger as shown.

# **T-guide Installation** Using the T-guide screws, attach the T-guide to the floor by aligning the edge of the guide with the edge of finished opening as shown above.

Plumb the door before fastening door guide to floor.



Goldberg Brothers barn door track and hardware sets come with a one-year manufacturer's warranty for defective parts under normal installation and use. Warranty is subject to repair or replacement of defective components at manufacturer's discretion and does not include installation costs

Goldberg Brothers does not warrant the loss of finish at points where roller is in contact with track. Goldberg Barn Track is sold as a rustic finished hardware and Goldberg does not warrant the imperfections seen through the finish in the steel parts. It is part of the look.

With the exception of our stainless steel products, Goldberg Brothers does not warrant any products installed and used outdoors or where they are exposed to weather, running water or water condensation. Under these conditions, rust and other damage will naturally occur.

This warranty does not include loss or defects caused by elements outside the control of Goldberg Brothers, Inc., such as natural disasters, weather, fire, water leakage, abuse, improper installation, or anything else deemed out of the control of Goldberg Brothers, Inc.

### **Basic Installation Layouts**

**Track Installation** 

