

# ASSEMBLING INSTRUCTION

Desc 38420 - AMPYANG SIDE TABLE BUBUT KD

NAIL SCREW ( 12 pieces )



1. TEAK TRAY SLACE ( TOP )
- 2, TEAK LEG 3 PIECES ( BOTTOM )



1. Put the tray on the floor
2. Take and Put the leg to the the tray slice and match with the number
- 3, Match the insert to the insert bolt hole
4. Lock the leg manually w hand rotate the right and unlock the teak legs rotate to the left



1. after finish put the side table in the normal position.
2. Put the side table in the flat media( floor ) to check balance and the strenght