## KITCHEN & BATH INSTALLATION INSTRUCTIONS Angle Stop

## Instructions:

- 1. Apply thread sealant tape to threads (1).
- 2. Screw valve body (2) onto pipe (3).
- 3. Place nut (4) and ring (5) on tube (6).
- 4. Insert tube (6) into valve.
- 5. Wrench tighten nut (4) onto valve.
- 6. Stop any leaks by tightening nuts slightly.



www.kingstonbrass.com TOLL-FREE CUSTOMER SERVICE: 1-877-2-KBRASS TECHNICAL SUPPORT E-mail: service@kingstonbrass.com 12775 Reservoir Street, Chino, CA 91710