

Traditional (non-woven)

Installation Instructions:

1. Remove all old wallcovering (to remove the remains of old paste try using a squirting bottle with water and a few squirts of washing up liquid. This works perfectly well on most wallcovering paste.)
2. Remove peeling paint remnants
3. Smooth out any rough surfaces (although the glass-fibre and glass textile products will cover small cracks and uneven surfaces.)
4. Clean with a damp cloth
5. Prior to beginning all surfaces should be dry.
6. We recommend the use of Pro Clear 880 pastes (standard non-woven wallcovering paste) or similar solvent free products (solvent based or dispersion pastes can result in the removal of inks)
7. Paste the wall or surface
8. Hang the way one would hang any non-woven wallcovering
9. Use a damp cloth to remove any excess wallcovering paste from the media.
10. Enjoy your new decor!