



Step 2. Twist 3 Rungs (C) to attach Right Leg (B) to the unit as shown in diagram 2.

Tip: Align Left Leg (A) and Right Leg (B) parallel to one another. Make sure both ends of the Rung (C) are inserted in the holes simultaneously while twisting to ensure a tight fit.

