









ASSEMBLY INSTRUCTION

Item: 6202-90867 DKW Moreno 6/0-6/6 Box Tufted Headboard
 6202-90868 DKW MORENO 6/0-6/6 Box Tufted Footboard
 6202-90863 DKW MORENO 6/0 Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK

NO	DRAWING	DESCRIPTION	SIZE	Q'TY
A		Screw	8#*1"	10pcs
B		Threaded Rod	Φ5/16"*4-1/2"	8pcs
C		Nut	Ø5/16"*12	8pcs
D		Lock Washer	Φ5/16"×12×3	12pcs
E		Curved Washer	L32*13*8	8pcs
F		Hex Wrench	12MM	1pc
G		Hexagonal Bolt	Φ5/16"×1-1/2"	4pcs
H		Flat Washer	Φ5/16"×19×2	4pcs

