ASSEMBLY INSTRUCTION FOR ACME FURNITURE MODEL # 97384

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, Identify and count all parts and metal hardware. Compare with parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local fumiture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needde.

******* Do not fully tighten screws until fully assembled *******

COMPONENT PARTS			
DESCRIPTION	PART NAME	2	Q`TY (PCS)
1	Top Panel		1
2	Side Panel		1
3	Side Panel		1
4	Door Leaf		2
5	Shelf		1
6	Bottom Panel		1
1	Cross Bar	()	1
8	Cross Bar	(· · · · · · · · · · · · · · · · · · ·	1
9	Back Panel		2
HARDWARES REQUIRED			
A Ca	am lock	13 PCS	
(B) ∗ Ca	am bolt	13 PCS	
	am nut	13 PCS	
D 🕬 Wa	ood dowel	13 PCS	
E Do Ha	old hands	2 PCS	
(F) 🛏 Ba	olt \$\$6x25mm \$	2 PCS	
G E	inge	4 PCS	
(H) 🦝 So	crew Ø6x15mm	16 PCS	-

Attention:

******* Some number parts listed on the instruction sheet may not be in parts bag as they may be assembled. Carefully check parts and packing materlals prior to odering replacements.









How to assemble:

STEP 13

