



ASSEMBLY INSTRUCTION

Item: 5183-90651 5/0 Uph Shelter Headboard-Carbon
 5183-90851 5/0 Uph Shelter Headboard-Taupe
 5183-90852 5/0 Shelter Footboard
 5183-90853 5/0 Shelter Rails

Thank you for purchasing this quality product. Be sure to unpack carefully looking for small parts which may have come loose during shipment.

Read all instruction and study the drawing carefully before starting the assembly process:

HARDWARE PACK OF HEADBOARD

NO	DRAWING	DESCRIPTION	SIZE	Q'ty
A		FLAT WASHER	Ø5/16"×19×2	8pcs
B		LOCK WASHER	Ø5/16"×12×3	8pcs
C		BOLT	Ø5/16"×2"	8pcs

HARDWARE PACK OF HEADBOARD

NO	DRAWING	DESCRIPTION	SIZE	Q'ty
E		THREADED ROD	Ø5/16"×4-1/2"	8pcs
F		FLAT WASHER	Ø5/16"×19×2	8pcs
G		LOCK WASHER	Ø5/16"×12×3	16pcs
H		BOLT	Ø5/16"×12	8pcs
I		HEX Wrench	12mm	1pc
J		SCREW	8#×1"	8pcs
M		BOLT	Ø5/16"×1"	8pcs
N		Curved Washer	Ø5/16"	8pcs

