

Assembly Instruction For 21151

- 1. Thread the nipple into coupler inside the fabric shade then fix by hex nut.
- 2. Place the glass diffuser to the nipple.
- 3. Put the cap, arm and cap 1 to the nipple, then secured by finial
- 4. Put the etched shade on the fabric shade

