

Cast Iron Clawfoot

Read the instructions below and follow all local plumbing and building codes.

Unpack and inspect your new feet for any shipping damages and ensure no pieces are missing.

If any damages are discovered DO NOT INSTALL and contact customer support at 877-795-5684.

You may also call our customer service for any other assistance with our products

TOOLS AND MATERIALS NEEDED :

(4) Clawfeet	(4) Bolts	(4) Nuts	(4) Flat Washers
(4) Lock Washers	(4) Metal Shims	(4) Plastic Shims	
17mm Socket Wrench			



Before installing feet, please take some time to notice if there are letters on the bottom of your tub and back of each foot. If so, the letters will indicate the location of each foot. If there are no letters, measure each foot. Two feet should be shorter than the other two by nearly 1/4". These will be used on the side of the tub with the drain, to allow the tub to drain properly. Then ensure each foot fits properly & securely before fully installing. Though they are not always necessary, we have supplied metal and plastic shims for secure and level installation.

1. For each foot a bolt, flat washer, lock washer, and a nut has been supplied.

2. While the tub is upside down, slide a bolt threads up, down the bolt slot on the bottom the the tub. Apply a metal shim if the bolt feels loose.



3. Slide the correct foot down onto the bolt and place the flat washer and lock washer down on the bolt in that order. Plastic shims are supplied if needed.



4. Making sure the foot is properly aligned, screw the nut onto the bolt and using your 17mm socket wrench, tighten to secure.



5. Repeat the steps above for each foot.