

CHIC TEAK

Assembly Instruction

INSTRUCTION DE MONTAGE
MONTAGEANLEITUNG
SAMLEVEJLEDNING

**MAKE SURE THE LETTERS
MATCH BEFORE ASSEMBLING**



**Make sure to use Gorilla Glue (Not Included)
on all wood joints before assembly**

Code

AM146

HARDWARE



- a. 60mm Screw x 2pcs
- b. 45mm Screw x 2pcs



- c. 30mm bolt x 2pcs

Tool



Socket Wrench 4m/m Ht

Total Section

4 Section