WamBam Sturbridge Vinyl Yard & Pool Gate w/Stainless Steel Hardware (48" H x 48" W) (Adjustable Width)



REFLUS A Important stuff to know about installing your WamBam gate.



This gate is designed to be integrated with our WamBam Sturbridge Vinyl Yard & Pool Fence - 4' High. (This gate can also be used in any opening that is 50" wide or less by trimming down both the top and bottom rail).

1-877-778-5733 www.wambamfence.com

1 - Read Over Fence Instructions First

Your gate and fence will work better together as an integrated solution if you first take the time to read and understand your fence instructions.

2 - Pre-Assemble the Gate Frame (without pickets)

Please do not screw your gate frame together until you have first temporarily assembled the gate. In other words, do a dry run first.

This will ensure three things:

- a) That you have everything necessary to complete the gate.
- b) That you will have assembled the gate in the correct order.
- c) All the pieces fit and function properly.

It's easier to trouble shoot when things are not screwed together. After you assemble your gate correctly, please disassemble as necessary and use screws to permanently assemble the gate.

3 - Ideally, Install Your Gate Posts <u>Before</u> Your Fence Posts

Your fence panels will be more forgiving for a custom fit than your gate. Ideally, position and install your gate posts before you do anything else, or very early on in the process of setting up your fence run.

4 - Ideally, <u>Do Not</u> Hang Your Gate System Off a Single Non-Supported Post

Your gate will perform better and last longer if your hinge post is connected to a panel of fence which is connected to another post. The weight strain will be transferred unto two posts versus just one. Installing fence panels on both sides of your gate is the ideal in all situations. If this is not possible because of space restrictions, please contact us for alternative solutions to overcome.



For more information, contact us at 1 877-778-5733.







Install Your Gate Posts

<u>Before</u> Installing Your Fence Posts.





PRODUCT OVERVIEW



For more information, contact us at 1 877-778-5733.



DETAILED ASSEMBY INSTRUCTIONS

STEP 1 Assemble the Gate Frame Bottom & Sides





Completely assembled gate shown

A - Insert the bottom rail <u>ALL THE WAY</u> until it <u>BOTTOMS OUT</u> inside gate bracket



- B Insert the bottom rail <u>ALL THE WAY</u> until it <u>BOTTOMS OUT</u> INSIDE GATE BRACKET
- C Insert vertical gate stiles. They will <u>BOTTOM OUT</u> against bottom horizontal rail

Fasten gate brackets to internal members through inside of frame using screws.

STEP 2 Assemble Pickets & Assemble the Gate Frame Top



A - Insert top rail <u>ALL THE WAY</u> until it BOTTOMS OUT inside bracket



WamBam Sturbridge Vinyl Yard & Pool Gate w/Stainless Steel Hardware









C - Insert pickets in the proper order into the bottom rail

D - Slide top rail with brackets down over the pickets and vertical gate stiles

E - Complete assembled gate frame shown





A - Fasten gate hinges and gate latch onto the gate brackets with screws.

STEP 5 Position, Adjust & Algn Gate/Secure Hinges to Posts



A - Use temporary spacers or blocks to rest the gate on during alignment and installation

For more information, contact us at 1 877-778-5733.

WamBam Sturbridge Vinyl Yard & Pool Gate w/Stainless Steel Hardware



Sam

B - Fasten hinges to post with screws





WamBam Sturbridge Vinyl Yard & Pool Gate w/Stainless Steel Hardware



C - Hinges can be adjusted moderately to bring gate into level alignment with post



Latch is designed for left and right hand applications. Temporarily remove. the spring, bolt and reverse paddle portion as necessary.

