Fontana 2 Functions Rain & Mist Shower Head Set With Shower **Body Sprays** 100-1000 (1) min 100 mm MAX 1000 mm MAX 30 mm 2 3 4 5 6 Fijar la ducha (1) a la placa me-diante los tornillos correspondien-tes, utilizando el adaptador espe-cial (S) para el ajuste correcto. Fix the shower head (1) to the plate with the appropriate screws, using the special adaptor (S) for correct tightening. Fixer le plafond de douche (1) à la plaque avec les vis prévus à cet effet, en utilisant l'adaptateur spécial (S) pour le serrage correct. Fixar o chuveiro (1) à placa com os parafusos apropriados, utili-zando o adaptador especial (S) para a fixação cor-reta. 8 3 1/2" 9 5/8" 4 1/2" 5 3/8"-5 3/8" 12 5/8"-C. В. A: 0.91" B: 8.66" В G1/2 900 025 200 Note: In 2856007 (PC) model Anmerkung: Für die Modelle 2856007 (PC). Attention: pour les modéles 2856007 (PC) Внимание: Для моделей 2856007 (PC) Atención: Para los modelos 2856007 (PC) Attencione: Per i modelli 2856007 (PC) 爾 - 3 Finished wall Ausbauwand Panneau de finition Отделочная стенка Pared de acabado Parete di finitura 3 Note: In 2852007 (PC), 5113700 (PC) model Anmerkung: Für die Modelle 2852007 (PC), 5113700 (PC) Attention: pour les modeles 2852007 (PC), 5113700 (PC) Внимание: Для моделей 2852007 (PC), 5113700 (PC) Atención: Para los modelos 2852007 (PC), 5113700 (PC) Attenzione: Per i modelli 2852007 (PC), 5113700 (PC) 3.2 Note: In 5113700 (PC) model Anmerkung: Für die Modelle 5113700 (PC). Attention: pour les modèles 5113700 (PC) Внимание: Для морелей 5113700 (PC) Atención: Para los modelos 5113700 (PC) Attenzione: Per i modelli 5113700 (PC) H Finished wall Ausbauwand Paroi de finition Отделочная стенка Pared de acabado Parete di finitura D A G1/2* 1 This General diagram and installation instructions are not intended for any specific

model, but is presented as a general guideline for Installations!