

For all non-disposer installations.

For disposer applications follow the directions supplied with the disposer.

## STEP 1



## STEP 2

Properly seat **Drain Body** into Perfect Drain.

Place Gasket over Perfect Drain.

Install Housing over Perfect Drain.

Thread Lock Nut onto Drain Body.

Place Poly Washer on Tailpiece.

Install Tailpiece Assembly onto Drain Body with Coupling Nut.

Check for leaks and place **Strainer Basket** into **Drain Body**.



## BE CAREFUL TO NOT OVER TIGHTEN THE FITTINGS.

In keeping with our policy of continuing product improvement, Elkay reserves the right to change product specifications without notice. Please vist elkayusa.com for most current version of Elkay product specification sheets. This specification describes an Elkay product with design, quality, and functional benefits to the user. When making a comparison of others producers offerings, be certain these features are not overlooked.

**Elkay** 2222 Camden Court Oak Brook, IL 60523 ©2011 Elkay elkayusa.com