GOLDBERG BROTHERS BARN DOOR HARDWARE

Premium Series J-strap hardware set - Installation Instructions 60013H-*, 60015H-*, 60015UH-*

J-strap hangers (2) Track stops (2)

T-guide (1) T-guide screws (2)

Carriage bolts (4) Lock washers (4)

Included Hardware Washers (6) Anti-jump blocks (2) Hex lag bolts (6)

Basic Installation Layouts

Anti-jump block screws (4)

Spacers (6) Hex nuts (4)

Felt Pads (2) Rubber bumper bands (2)



³∕^s″

Bumper:

Place one of the provided rubber

bumper bands around each stop OR

For each hanger, place one felt pad

strip on the track stop or the edge

of the hanger as shown.

DOOR

Anti-jump block

FINISHED OPENING



Premium hardware set installed to track trim board that is equal to, or thicker than casing, base, or other trim.



Premium hardware set + 1/2" extension kit installed where casing, base, or other trim is up to ½" thick.

Using the carriage

bolts, hex nuts and

the diagram.





Premium hardware set +%" or 1¼" extension kit installed where casing, base, or other trim is greater than ⁵/₈".



In the closed position, the door should overlap the wall a minimum of 3/8" the top and a minimum of 1/2" on both sides. The edge of the door

13/4"

31/2"

1″

- 1/2"

DOOR EDGI

3'

should align with the end of the track.

Note: After the door is hung from the track, the anti-jump blocks can be installed directly behind the J-strap hanger.

T-guide Installation



Using the T-guide screws, attach the T-guide to the floor by aligning the edge of the guide with the edge of the finished opening as shown above.

Plumb the door before fastening door guide to floor.



Goldberg Brothers barn door track and hardware sets come with a one-year manufacturer's warranty for defective parts under normal installation and use. Warranty is subject to repair or replacement of defective components at manufacturer's discretion and does not include nstallation costs

Goldberg Brothers does not warrant the loss of finish at points where roller is in contact with Golderg brothers does not warrant the imperfections seen through the finish in the steel parts. Coldberg Brothers does not warrant the imperfections seen through the finish in the steel parts. It is part of the look.

With the exception of our stainless steel products, Goldberg Brothers does not warrant any products installed and used outdoors or where they are exposed to weather, running water or water condensation. Under these conditions, rust and other damage will naturally occur.

This warranty does not include loss or defects caused by elements outside the control of Goldberg Brothers, such as natural disasters, weather, fire, water leakage, abuse, improper installation, or anything else deemed out of the control of Goldberg Brothers

Door Prep and Hanger Installation

Track Installation



/19/19