

0092 Queen Bed

Assembly Instructions







0092 Queen Bed

Assembly Instructions

1 Bolt the Bed Slats (R) to the Side Rail (M).







WI-0622







