

**CHIC TEAK**

## Assembly Instruction

INSTRUCTION DE MONTAGE  
MONTAGEANLEITUNG  
SAMLEVEJLEDNING

**MAKE SURE THE LETTERS  
MATCH BEFORE ASSEMBLING  
NEED ASSEMBLY ASSISTANCE?  
CALL US AT 866-814-8325**



**Make sure to use Gorilla Glue (Not Included)  
on all wood joints before assembly**

Code

**HJ088**

Hardware



Screw (16 Pcs)

Tool

Total Section

**3 Section**