

ASSEMBLY INSTRUCTIONS

CAUTION:

THIS ITEM IS MADE OF LAMINATED PARTICLE BOARD AND MEDIUM DENSITY FIBRE BOARD TO BE ASSEMBLED ON A DRY,SOFT,SMOOTH AND CLEAN SURFACE. DO NOT USE DETERGENT OR CHEMICAL.
AVOID DAMP AND DIRECT SUNLIGHT.

STEP 1 CHECK YOUR HARDWARE		
	SCREW M3 X 20	4 PCS
	CORNER BLOCK	4 PCS
	SCREW #9 X 1 1/2"	16 PCS
	WOOD DOWEL M6 X 25	16 PCS
	WOOD DOWEL M6 X 50	2 PCS
	RETRACTABLE DOOR STUD WITH SPRING	4 PCS
	MAGNET WITH LEG	2 PCS
	MAGNET PLATE	2 PCS
	SCREW M3.5 X 12	4 PCS
	PAN HEAD SCREW #6 X 20	2 PCS
	KNOB	2 PCS
	STICKER	16 PCS

TOOLS REQUIRED:	
HAMMER	SCREW DRIVER

STEP 2

WOOD DOWEL M6 X 25
DETAIL A

WOOD DOWEL M6 X 50
DETAIL B

STEP 3

MAGNET WITH LEG
DETAIL A

MAGNET PLATE
DETAIL B

STEP 4

DETAIL A

DETAIL B

DETAIL C

SCREW M3.5 X 12

MAGNET PLATE

STEP 5

WOOD DOWEL M6 X 50
DETAIL A

STEP 6

TOP

DETAIL A

DETAIL B

DETAIL C

SCREW #9 X 1 1/2"

STEP 7

TOP

DETAIL A

DETAIL B

DETAIL C

SCREW #9 X 1 1/2"

STEP 8

TOP

DETAIL A

DETAIL B

STEP 9

TOP

DETAIL A

DETAIL B

DETAIL C

SCREW #9 X 1 1/2"

STEP 10

DETAIL A

DETAIL B

BACK VIEW

SCREW M3 X 20

STEP 11

DETAIL A

DETAIL B

TOP

DETAIL A

DETAIL B

DETAIL C

DETAIL D

STEP 12

DETAIL A

DETAIL B

OR

STICKER

DETAIL A