

ASSEMBLY INSTRUCTION

ITEM NO:71543

STEP1:INSERT (1) INTO

THE HOLE IN THE DECK

STEP2:HOOK SHROUDS TO

THE PLACES (2), (3), (4)

(5), (6) AND (7)

RESPECTIVELY.

