

# MAXIM Assembly Instruction For 21564TWPN

1. Tighten the tube(G) to the coupler(N);
2. Tighten the coupler(F) to the tube(G);
3. Tighten the tube(E2) to the coupler(F);
4. Tighten the tube(E1) to the tube(E2);
5. Tighten the tube(E) to the tube(E1);
6. Tighten the coupler(D) to the tube(E);
7. Insert the bulb(O) into socket
8. Hang the crystal string(CRS21560PN-C),(CRS21560PN-I),(CRS21560PN-H) to the metal ring(S),(R) by mix
9. Hang the crystal string(CRS21560PN-B),(CRS21560PN-G),(CRS21560PN-F) to the metal ring(T),(Q) by mix
10. Hang the crystal string(CRS21560PN-A),(CRS21560PN-D),(CRS21560PN-E) to the metal ring(P),(U) by mix

