

Assembly Instruction For 11800

- 1. Screw the nipple into the coupler.
- 2.Attached the galss on the nipple then secure by hex nut.
- 3.Attached the cap on the nipple then secure by finial.

