






ASSEMBLY INSTRUCTION FOR ACME FURNITURE


MODEL#LV52151 /LV52281 /LV52286

Thank you for purchasing the quality product. Be sure to check all packing material carefully for small parts which may have come loose inside the carton during shipment. Separate, identify and count all parts and metal hardware. Compare with all parts list to be sure all parts are present. If any part(s) are missing or damaged, please contact your local furniture dealer. For efficient and speedy service, please indicate the model number and code letter of part(s) needed.


*** Do not fully tighten screws until fully assembled ***

DESCRIPTION	COMPONENT PARTS	
	PART NAME	Q'TY (PCS)
①	SEAT BODY 	1
②	LEFT BACKREST 	1
③	RIGHT BACKREST 	1
④	LEFT EAR 	1
⑤	RIGHT EAR 	1


STEP 1: Attach Left Backrest (2) and Right Backrest (3) to Seat Body (1).




STEP 2: Attach Left Ear (4) and Right Ear (5) to Left Backrest (2) and Right Backrest (3).



STEP 3: Cover back of the Seat Body attaching it with velcro.



Completed.



Attention

***Some number parts listed on the instruction sheet may not be in parts bag as they may already be assembled. Carefully check parts and packing materials prior to ordering replacements.