



Assembly Instruction For 25133

1. Screw the tube (C) to the coupler (D) till tight
2. Screw the tube (B2) to the tube (C) till tight
3. Screw the tube (B1) to the tube (B2) till tight
4. Screw the tube (B) to the tube (B1) till tight
5. Screw the ceiling pan (A) to the tube(B) till tight
6. Install 9*60W G9 bulbs into socket (Bulbs included)
and please noted that the bulb can't be hit the flat metal

