ASSEMBLY AND INSTALLATION INSTRUCTIONS

WARNING: TO AVOID RISK OF ELECTRICAL SHOCK, BE SURE TO SHUT OFF

POWER WHILE INSTALLING OR SERVICING THIS FIXTURE.

NOTE: Before installing, consult local electrical codes for wiring and grounding requirement.

white wire

outlet box screv

3213 3215 3217 outlet

plastic wall anchor

anchor screw

canopy

socket

socket ring

glass shade

- 1. Push the plastic wall anchor in the holes pre-drilled in the ceiling in place.
- 2. Attach the backplate to outlet box using 2 outlet box screws upwards.
- 3. Make wire connections:
- -Attach ground wire to house ground wire using a wire nut or attach them to the cross bar with a green ground screw.
 -Attach white wire from light to white wire from power source with a wire nut.
 -Attach black wire from light to black wire from power source with a wire nut.
 Observing: positive wire with positive wire, negative wire with negative wire, ground
- wire with ground wire.
- 4. Tuck the wire connections neatly into the outlet box.
- 5. Attach the canopy to the ceiling and let the 2 mounting screws pass through the 2 pre-drilled holes on the canopy and fix it in place by ball nuts.
- 6. Place the glass shade onto the socket and secure it with socket ring.
- 7. Install bulb.(not included) (Please do not exceed the maximum capacity which is recommended on the fixture.)
- 8. Turn on the power at fuse or circuit box.