1 OF 4

ASSEMBLY INSTRUCTIONS

Read this instruction carefully. See hardware and furniture part list for guidance. Be sure all parts are complete, before you assemble. Place all wooden furniture parts on a clean and flat soft surface to prevent from being scratched. Follow the figure to start assembling.

- CAUTIONS: 1. Do not FULLY TIGHTEN the nut or nut bolt until all nut or bolt is ready assembed.
 - 2. Do not OVER TIGHTEN the nut or bolt to avoid causing damages to the thread.
 - 3. Keep all hardware parts out of reach of children.

NOTE: THE LIST AND QUANTITY SHOWN ARE FOR 1 UNIT ASSEMBLY.

Tool needed: Screwdriver (not provided).

| • | PART LIST | | | ıL |
|---|-----------|---------------------------|-------|----|
| • | ITEM | DESCRIPTION | QTY | ı |
| | Α | BACK | 1PC | ıL |
| | В | SEAT | 1 PC | l |
| | С | FRONT LEG | 2 PCS | l |
| | D | FRONT LEG SUPPORT (METAL) | 1 PC | l |
| | Е | SIDE RAIL | 2 PCS | ŀ |
| | | | | |

| | HARDWARE LIST | | | |
|------|-------------------------------|--------|--|--|
| ITEM | DESCRIPTION | QTY | | |
| 1 | JCBC BOLT M6 x 80mm | 4 PCS | | |
| 2 | JCBC BOLT M6 x 50mm | 5 PCS | | |
| 3 | WOOD SCREW M4 x 20mm | 2 PCS | | |
| 4 | WOOD SCREW M3.5 x 12mm | 8 PCS | | |
| 5 | WOOD SCREW M3.5 x 16mm | 12 PCS | | |
| 6 | M6 FLAT WASHER | 9 PCS | | |
| 7 | M6 SPRING WASHER | 9 PCS | | |
| 8 | M4 ALLEN KEY (BALL SHAPE) | 1 PC | | |
| 9 | 5005 2 HOLE L BRACKET (BLACK) | 2 PCS | | |
| 10 | 5003 2 HOLE L BRACKET (BLACK) | 8 PCS | | |
| 11 | WOOD SCREW M4 x 45mm | 4 PCS | | |









