



# Installation instruction

## Stix

### Required additional material:

- Cleaning utensils, to clean the wall
- Spirit level
- Mounting aid (included with the product)

#### 1. Prepare the wall

First clean the wall and remove all foreign objects.

#### 2. Pull off the adhesive foil

Pull off the foil of the slats. Make sure that the adhesive surface is not soiled.

#### 3. Attach the slats

Press the slats firmly onto the wall. Always use a spirit level and the enclosed attachment aid for an equal distance of 16,5 mm.

## Comfort / Professional / Blockbuster

### Additional material required when screwing acous to the wall/ceiling:

- Cleaning utensils to clean the wall
- Spirit level
- Sandpaper
- Cordless screwdriver/drill, depending on surface
- Screws / Dowels

#### 1. Prepare the wall

First clean the wall and remove all foreign objects.

#### 2. Prepare the panels

Pre-drill the panel and substrate for a clean and stable result.

#### 3. Attach the panels

Screw the screws through the HDF/felt into the wall. Use a spirit level for both options.

### Required additional material, if you choose the adhesive variant:

- Cleaning utensils to clean the wall
- Spirit level
- Installation glue
- Two wallpaper trestles

#### 1. Prepare the wall

First, clean the wall and remove all foreign objects.

#### 2. Prepare the panels

Spread the glue on the back or directly on the wall.

**Tip:** Take two wallpapering trestles to help.

#### 3. Attach the panels

Press the panels firmly against the wall.