

## **Assembly Instruction For21261**

- 1.Attach the rubber washer 1 to the nipple then attach the nipple to the combination.
- 2.Attach the rubber washer 2 to the glass then fix the combination and glass by hex nut and finial.

