



**MAKE SURE THE LETTERS
MATCH BEFORE ASSEMBLING
NEED ASSEMBLY ASSISTANCE?
CALL US AT 866-814-8325**

Assembly Instruction

**INSTRUCTION DE MONTAGE
MONTAGEANLEITUNG
SAMLEVEJLEDNING**



***Make sure to use Gorilla Glue (Not Included)
on all wood joints before assembly***

Code

Hj384

Hardware



(Screw 8 Pcs)

Tool

Total Section

3 Section