



Assembly Instruction For22296

- 1.Put the laser cut shade (Q) on the metal cross framework (L),then make flat screw (k) through metal cross framwork (L),and laser cut shade (Q), then tighten round nut (N) ;
- 2.Put the fabric shade (U) on the metal cross framwork (L),then tighten the ball nut (W) with flat screw (K) ;
- 3.Tighten the tube (I) with tube (J);
- 4.Tighten the coupler (H) with tube (I)
- 5.Tighten the tube (G2) with couper (H);
- 6.Tighten the tube (G1) with tube (G2);
- 7.Tighter the tube (G) with tube (G1);
- 8.Tighten the sitting pan (F) ,plate (E),star washer (C) on the tube (G),then tighten the hex nut (A) with tube (G) ;
- 9.Install the light bulb (V) into socket ;
- 10.Hang the crystal chains (D),(B) on circle (P);
- 11.Hang the crystal chains (R),(M) on circle (O);

