22" Venice Multifunctional Shower Polished 2 Way Rainfall Shower Sets



INSTALLATION INSTRUCTIONS







- (2) SUPPORT BRACKET SCREWS(4) F803-5 XP2
- 3 ROUGH-IN F803-5 XP3
- (4) ROUGH-IN SCREWS(4) F803-5 XP4
- (5) BLANK PLUGS(2) F803-5 XP5
- 6 PLASTER GUARD F803-5 XP6
- SUPPLY NOZZLE FILTERS(2) F803-5 XP7
- SUPPLY NOZZLES(2) F803-5 XP9
- (1) SUPPLY NOZZLE CAPS(2) F803-5 XP10
- (1) ALLEN WRENCH FOR BLANK PLUGS F803-5 XP11
- (2) SET SCREWS F803-5 XP12
- (3) ALLEN WRENCH FOR SHOWERHEAD F803-5 XP13
- SHOWERHEAD F803-5 XP14



When the finished wall is complete, remove the protective cover.



- Install the escutcheon, and handle. Tighten the set screw with an Allen wrench to secure.
- 5. Attach the shower arm escutcheon to the shower arm. Wrap the threaded portions of the shower arm with Teflon tape and connect the arm to the shower inlet. Adjust the direction of the water flow as needed. Attach the rainfall shower head to the shower arm.

VALVE EXPLODED VIEW:

1	SD10101000200
2	M0105004
3	SD15617000100
4	SD10117000400
5	SD10117000500
6	SD15619000300
7	OXQ50030
8	FX0402
9	SD10117000600
10	SD10119000800-1
11	SD10119000700-1
12	M0305022
13	SD10119000900
14	M0805032
15	SD10119001000
16	SD10119001100
17	M110405









- Install the valve body. Wrap the threaded portion of the joints in Teflon tape and connect the water inlet and outlet.
- Put the protective cover on the valve body and finish the shower wall.





7 WALL MOUNT INSTALLATION

Place Wall Mount (7A) onto wall and insert Mounting Screws (7B) through Wall Mount Holes (7C) and tighten until Wall Mount (7A) is flush with the wall. Do Not Over Tighten! Insert Front Cover (7D) into Wall Mount (7A).



8 DROP ELBOW & HOSE INSTALLATION

into Drop Elbow Outlet (8E) by turning Hex Hose Fitting (8D).

Apply PTFE plumbers tape on both ends of Pipe Niple (8A) (not included). Screw Pipe Niple (8A) into the elbow inside the wall. The Pipe Niple (8A) is to project 1/4*-3/8* from the finished wall. Screw Drop Elbow (8B) onto Pipe Niple (8A) and tighten until Drop Elbow (8B) is properly positioned and flush to the finished wall. Place Rubber Seal (8C) inside Hex Hose Fitting (8D). Connect Hex Hose Fitting (8D)



5 HOLE LOCATIONS FOR WALL MOUNT

Remove Front Cover (5A) from Wall Mount (5B). Use Wall Mount Screw Holes (5C) to place the desired location. Using a punch or awl, tap the screw hole locations. Holes must be vertically aligned.



6 ANCHOR INSTALLATION

Drill two ¹/4" Dia. Holes (6A). If installing into a stud, drill two ¹/8" Dia. holes and do not use Anchors (6B). Insert Anchors (6B) into Holes (6A) and tap flush with wall.



9 UNIT START UP

Turn on hot and cold water supplies, and check all connections for leaks.



10 FINAL FLUSHING

For final flushing, turn valve on and allow water to run through the Hose (10A) for several minutes. Allow water to run for several minutes untill all foreign matter clears the line.



Make sure Hand Shower (11C) is securely tightened to Hose (11D).