## Assembly Instruction For 20099

## Attach the glass and cap on the socket then secure by socket ring.

