

# ASSEMBLY INSTRUCTIONS KBC - OZ 60" Double Sink

-Please Unpack all parts and check against parts list on this instruction sheet before discarding the packaging . -Note: We recommended at least 2 people assist in installation to avoid injury or damage to the product.

Screw (A)

#	ŧ	Part Description	Dimension		QTY
1		Floating vanity	1522x585x712mm(KBC 602)		1 (pc)
2	2	Wooden Hanger	220x50x20mm(KBC 602)	B	5 (pcs)
3	3	Plywood panel	1472x160x18mm (KBC 602)	B	1 (pc)

	RTA hardware					
#	Drawing	Description	Q'ty			
Α	(	Long screws (Ø8x50mm)	21 (pcs)			
в	<b>4</b>	Short screws (Ø8x35mm)	20 (pcs)			

### Tools

. Screwdriver, drill , hammer .....( not included )

## Assembly Instructions

## Step 1 :

- Hold the plywood panel (3) against the wall and align the screw holes with your stud locations.
- Use a writing untencil to mark the location.
- See Figure 1 for recommended mounting height
- Use long screws (A) and drive them through the plywood panel to secure.

# Wall studs



## Step 2 :

## Screw (B)

- Use short Screws (B) to attach the wooden hanger (2) to the plywood panel (3).
- Use Figure 2 as reference for mounting height.



- Hang the vanity (1) on the wooden hanger (2).
- Use Figure 3 as reference for recommended final mounted height .





www.Kitchenbathcollection.com



# ASSEMBLY INSTRUCTIONS KBC - OZ 60" Double Sink



2 of 2