ASSEMBLY INSTRUCTIONS

ITEM #: WF303670AAK

Thank you for purchasing this quality product. Be sure to check all packing material carefully for small Hardware which may have come loose inside the carton during shipment. Identify and count all hardware and compare with the hardware list below

ASSEMBLY INSTRUCTION:

- 1. Remove hardware from box and sort by size.
- 2. Please check to see that all hardware and parts are present prior start of assembly.
- 3. Please follow attached instruction in the same sequence as numbered to assure fast and easy.

N WARNING!


- 1. Don't attempt to repair or modify parts that are broken or defective. Please contact the store immediately.
- 2. This product is for home use only and not intended for commercial establishments.
- 3. Two persons are required for assembly.
- 4. Approximate assembly time: 1/2 hours
- 5. Component parts and fittings contained in the box.
 - Please sort out all parts before you begin to assemble the item.
 - This is to make sure you always use the correct part
- 6. It is STRONGLY RECOMMENDED that you ANCHOR this product.


Toppling furniture can cause serious injuries and death.

This product has not been fitted with an anchor strap.

To prevent your furniture from tipping forward it is strongly recommended

that you securely attach this product to a wall or other solid surface, using the anchor straps provided and appropriate fixings.






TOOLS NEEDED: Phillips Screwdriver



Wall Drill

Hammer





ASSEMBLY INSTRUCTIONS

WF303670AAK HARDWARE LIST





x34 Cam-bolts



(B)

x34 Cam-locks

Ф8*3/4"



x6 Dowels

Ф8* 1-1/8"





Dowels

x8

1/4" Ф8* 3/4"





x10

Bolts

Ф13* 1mm





Flat Washer

Ф10* 1mm






Spring Washer

4mm



Allen Key



x24 Screws

Ф8*3/4"





x20 Screws





x4






x4 Anchor



x2 Plastic tie




<u>x4</u>

Screws




V1


Screws





х4

Screws





























STEP 7





STEP 8






STEP 9

Place the Cabinet in the desired location against the wall. Mark the position of the attached Hooks on the wall and remove the Cabinet. Using one of the remaining Hooks (K) as a template, Place the Hook (K) under the marks on the wall and mark the two hole positions. Drill the holes for the Anchors (L) and insert the Anchors (L) into the wall. Attach position and connect the Hooks (K) together with Plastic Tie (M). Assembly is now complete.

Plastic tie



Screws

Screws

Page 12/13

MADE IN VIET NAM

