

Contemporary Lighting™

## Installation Instructions Model E20633-151PC

1. Turn breaker off for circuit on outlet where fixture is to be installed.

2.Remove mounting bracket from fixture and install to electrical box.

3. Adjust wire length to desired mounting height, and tighten strain relief screws to secure.

4. Wire fixture to wires in outlet box. Green wire is for Ground.

5.Install fixture to bracket and tighten screws at the ends of the canopy to secure.

6. Install glass onto socket using socket ring and spacer to secure.

7.Install maximum 60 watt E26 incandescent light bulb.

