CARE AND MAINTENANCE

Always use felt pads under allarticles to prevent discoloration or softening of the lacquer. Plastic and rubber bases on items can discolor wood. Wipe up spills immediately and avoid common hazards such as hot dishes,harsh solvents and abrasives. Cleaning should be done with a soft lint free cotton cloth dampened with water or furniture polish. On highly used surfaces we recommend applying a quality paste wax which should be used on a regular basis to provide additional protection from sratches and spills. How often you apply the wax depends on how much wear the furniture receives.

NOTICE

* Please make sure that you have all parts indicated before you begin assembly of this item
* This item should be assembled on a soft surface to prevent scratching the finish during assembly
* This item may require periodic tightening

Part List and Hardware List

PIECE	DESCRIPTION	PICTURE	QUANTITY
A	Leg		2X
B	Shelf 17-1/2"X7"		1X
C	Shelf 17-1/2"X11"		1X
D	Shelf 17-1/2"X14-2/5"		1X
E	Shelf 17-1/2"X17-3/4"		1X
H1	Allen bolt	M6X25mm	16X
H2	Allen key		1X
H3	Rubber pad		4X

SAFAVIEH
FURNITURE

Model# FOX4237

Product Dimensions:19-3/5"WX14-1/2"DX49-3/5"H

PREPARATION

Before beginning assembly of product, make sure all parts are present. Compare parts with package contents list and hardware contents list.
If any part is missing or damaged, do not attempt to assemble the product.
Estimated Assembly Time: 10 minutes.
Tools Required for Assembly (included): Allen Key

Step 1
Attach the shelf(B) to the legs (A),using Allen bolt(H1)
Tighten with allen key(H2)

Step 2
Attach the shelf(C) to the legs (A),using Allen bolt(H1
Tighten with allen key(H2)

Step 3
Attach the shelf(D) to the legs (A),using Allen bolt(H1)
Tighten with allen key(H2)

Step 4
Attach the shelf(E) to the legs (A),using Allen bolt(H1)
Tighten with allen key(H2)

Step 5
Attach the rubber pads(H3)to the bottom of legs(A)