


Item # : B50CYSL Assembly Instructions



Please visit our website for the most current instructions, assembly tips, report damage, or request parts. www.walkeredison.com


Revised 05/2017


General Assembly Guidelines

- I. Ensure that all parts and hardware are available before beginning assembly.
- II. Follow each step carefully to ensure the proper assembly of this product.
- III. Two people are recommended for ease in the assembly of this product.
- IV. The two main types of hardware used to assemble this product are : screws and bolts.
- V. A Phillips head screwdriver is required for the assembly of this product.



VI. Power tools should not be used to assemble this product.






Hardware List


Α	M6*60mm	Bolt	8	pcs
В	M4*32mm	Screw	14	pcs
С	Ø1/4"	Washer	8	pcs
D	Ø1/4"	Spring washer	8	pcs
E	M4mm	Wrench	1	рс




Philips head screwdriver required for assembly (not included)


The hardware quantities listed above are required for proper assembly. Some extra hardware may also have been included.






Secure parts (4,5) to legs (2,3) with screw (B), but don't tighten completely until Step 5.





Use wrench (E) to secure top panel (1) to legs (2,3) with bolt (A), spring washer (D) and washer (C). Tighten all bolts completely in this step.

Step 6



Place shelf (6) as per diagram to set it on top of the base frame.

