

SUPER COMBO 4400N

QUICK
REFERENCE

DIRECTIONS FOR USE

1 INSTALLATION

- Remove 2 Shipping Rods (located on back panel), this also releases a red tag which frees the power cord.
- Connect Hot & Cold Water hoses (included)
Note: Cold water hookup is needed for condensing drying
- Plug power cord into a 110V/60Hz outlet
- Insert hose into U-connector and insert into standpipe or over sink 24"-40" high
- Attach 4" vent hose (not included) on the exhaust outlet if Venting option will be used
- Venting/Condensing drying option - Press button for 5 seconds to select option (One time setup)

2 LAUNDRY PREP

- Load the machine to a maximum of 2/3 full
- Use High Efficiency (HE) detergent - approximately 1 tablespoon
- Use liquid fabric softener - items tumble more freely and dry faster

3 OPERATION

- WASH & Dry: Press Wash + Dry button - Press START
- WASH ONLY: Press Wash only button - Press START
- DRY ONLY: Press Dry only button - Press START

Note: Heat will not come on during wool cycle

4 WASHING TIPS

- DETERGENT: Use HE Detergent, Equator[®] is recommended
- FABRIC SOFTENER: Downey[®] is recommended to reduce wrinkles
- DELAY START: Press to delay start time upto 24 hours



+



5 DRYING TIPS

- Drying is 30% faster if liquid fabric softener is used
- In condensing dryer mode, fabrics will be damp to the touch when unloaded, but will air dry quickly
- Over-Drying will cause wrinkles
- Wrinkle Guard - Drum will tumble every 5 mins after end of Dryer cycle to reduce wrinkles

DIAGNOSTIC MENU

Code	Description	Component
E1	Door close	Door Switch
E2	Drain	Drain Pump
E3	Water inlet	Inlet Valves
E4	Water overflow	Pressure Switch
E5	Motor	Thermal Protector +Electronic Module
E6	Communication between display & electronic module	Communication Cable
E8	Dryer Malfunction	Temp. sensor (@rear-bottom of tub)
E9	Dryer Malfunction	Temp. sensor (@front of heater housing)
E10	Water fill	Water level sensor
E11	Dryer Malfunction	Temp. sensor (near the blow fan motor)
E12	Dryer Malfunction	Fan Motor
E13	Dryer Malfunction	Heating Element

Cycle	Wash Times		Approximate Dry Times	
	H	M	H	M
PreWash+Heavy	1	23	2	00
Heavy	1	08	2	00
STANDARD	0	55	1	40
Quick 20	0	20	1	20
Baby	0	40	1	00
Delicate	0	40	1	00
Wool	0	40	TUMBLE ONLY NO HEAT	
Quiet	0	35	1	00

For Questions or Service:
www.ApplianceDesk.com
1-800-776-3538