


Inside Your Home



These measurements serve as a reference for installing your hammock swing inside your home. You can adjust the height of your swing by adjusting the length of the strap, chain or rope used to install it. Just make sure that the bottom of your hammock swing is installed 2 ft away from the nearest wall and 2 ft above the ground.

